

MODEL NO.: ST-9215A/B/C
WATERPROOF ROUND SHAPE DIGITAL POCKET MULTI-STEM THERMOMETER

FUNCTION:

- A** ON/OFF, H/T, °F/°C FUNCTION
- B** ON/OFF, H/T, MAX/MIN (°F/°C) MEMORY RECALLING FUNCTION
- C** ON/OFF, °F/°C, MAX/MIN (°F/°C) MEMORY RECALLING FUNCTION



FEATURES:

- ONE HOUR AUTO SHUT OFF
- 133MM STAINLESS STEEL SENSOR PROBE
- MAX/MIN (°F/°C) MEMORY RECALLING
- TEMPERATURE UNIT °F/°C SELECTABLE
- DATA HOLD/TEST FUNCTION SELECTABLE
- 1 SEC. NORMAL TEMPERATURE SENSING TIME
- PROTECTIVE PLASTIC SLEEVE WITH CLIP
- LOW BATTERY INDICATOR

SPECIFICATION:

- MEASUREMENT RANGE: -50°C ~ +150°C OR -58°F ~+302°F
 -50°C ~ +300°C OR -58°F ~+572°F
- RESOLUTION : 0.1° FOR -19.9° ~ +199.9°, OTHERWISE 1°
- ACCURACY : ±1°C IN THE RANGE OF -30°C ~ +150°C
 ±1.8°F IN THE RANGE OF -22°F ~ +302°F
 ±1°C IN THE RANGE OF 151°C ~ +250°C, OTHERWISE MORE THAN ±2°C
 ±1.8°F IN THE RANGE OF 303.8°F ~+482°F, OTHERWISE MORE THAN ±4°F
- AMBIENT TEMPERATURE FOR PLASTIC CASING:
-10°C ~ +50°C OR +14°F ~ +122°F
- BATTERY : 1 X 1.5V "A76" SIZE(LR44,G13) OR EQUIVALENT

INSTALLATION:

- UNPACK THE THERMOMETER WITH CARE.
- UNSCREW THE BATTERY DOOR, INSTALL ONE "G10" SIZE (OR EQUIVALENT) BATTERY INTO THE BATTERY COMPARTMENT. THEN SCREW THE BATTERY DOOR.
- REPLACE NEW BATTERY WHEN THE LOW BATTERY INDICATOR APPEARS ON THE SCREEN.

OPERATION:

"ON/OFF" --- FOR POWER SWITCHING

- "°C/°F" --- TO SELECT DESIRED TEMPERATURE UNIT.
- "HOLD/TEST" --- PRESS ONCE, "HOLD" FLASH TO RETAIN READING FOR RECORDING.
- "MAX / MIN" --- PRESS ONCE TO RECALL MINIMUM TEMPERATURE TESTED. PRESS AGAIN FOR MAXIMUM TEMPERATURE TESTED. TESTING MODE WILL RESTORE AFTER 3 SECONDS

PRECAUTIONS:

- TO OBTAIN THE BEST RESULTS, THE PROBE TIP SHOULD BE IMMERSSED AT LEAST 10MM. INTO THE TESTED SUBSTANCE.
- REMOVE THE BATTERY FROM THE BATTERY COMPARTMENT IF THE THERMOMETER WILL NOT BE USED FOR LONG DURATION OF TIME OR DURING STORAGE.
- THE THERMOMETER CANNOT BE USED OR PUT INSIDE ANY OVEN OR MICROWAVE.